

User Manual for Matrix Maker

Version 3.8

I. Program Installation

To install the program, run the Setup.exe file.

The default folder for installation is

“C:\Program Files\Matrix Maker\Programmable Keyboard”.

II. PS/2 Keyboard and MSR Card Reader Driver Setup

This section is only for users using Windows 2000, Windows XP®, Windows Vista, Windows 7 and Windows 8 who have PS/2 keyboards or MSR card readers. The default folder for the driver files is "C:\Program Files\Matrix Maker\KB Driver". For the detailed instructions, please refer to the file, POSKB_DRV_SETUP.pdf, which is in the default folder.

Note:

1. PS/2 driver supports for 32-bit OS (Windows 2000, Windows XP®, Windows Vista, Windows 7 and Windows 8). Therefore, it is not allowed to program PS/2 keyboards or MSR card readers under 64-bit OS.
2. For USB keyboards or MSR card readers, as no driver is needed, it is allowed to program USB devices under 32 bit or 64 bit OS.


III. Keyboard Programming Software

The default location of the executable file is

"C:\Program Files\Matrix Maker\Programmable Keyboard\MatrixMaker.exe"

1. Select a keyboard

When the program runs, the Keyboard Category dialogue will appear.



To program with a keyboard, you should follow the below instructions.

1. Select the connection interface (PS/2, USB or RS232) of your keyboard.
2. Choose the correct model of your keyboard in the "Available Product" list. You should see the image of your keyboard in the "Preview" frame.
3. Select the country layout you want to program, and then press the "OK" button.

The following instructions are based on one of our models, S78A, but can also be applied for other models.

2. Edit Key Map


After selecting a model, you will be displayed with the default key layout which has no data for the programmable keys. You may notice that if you roll your mouse over certain keys on the layout image they will change to a light grey color. This indicates that the keys are programmable. Clicking the left mouse button on that programmable key will display a popup menu with options of assigning functions to that key. There are six methods to assign a function to the programmable key which will be explained in greater detail in the following sections. An example of the key map screen and the five programming functions are shown below.



[Note: Not all models have Key Lock.]

i. Key Code

In this method, you can assign any scan codes to a key.



In the above dialogue window, the most popular key codes (scan codes) are shown in the “virtual keyboard” area, plus a few special codes which are listed in the “Special Codes” area. Selecting a key from the “keyboard” area or double clicking an item in “Special Codes” area will add that key’s code to the “Mapping Sequence” list. You may also type codes directly from a connected keyboard. Up to 256 codes can be mapped to a single key position. Selecting a combination from the “Common Mapping” list will add the corresponding key codes into the “Mapping Sequence”.

Any key codes (scan codes) that are not selectable in this screen can be mapped by directly entering the hexadecimal code for that key into the box next to “0x” and pressing “Insert”.

For the definition of scan codes, please download Scan Code Translation Table from <http://download.microsoft.com/download/1/6/1/161ba512-40e2-4cc9-843a-923143f3456c/translate.pdf>.

For a PS/2 device, please enter a PS/2 Set 2 code. For a USB device, please enter a HID Usage ID in HID Usage Page 07.

Example

If you press “Shift”, “H”, “E”, “Shift”, “L”, “L”, and “O” buttons in the “virtual keyboard”, the “Mapping Sequence” list will be shown as in the above dialogue window. After programming this key code sequence and sending the updated mapping to the keyboard (covered in a later section), if you type this button in Notepad, it will display

“Hello” if the Caps Lock is off. However, it will display “heLLO” if the Caps Lock is on.


If you want to delete “O” in the above “Mapping Sequence” list, you can right click the “O” item. A popup menu with two options will appear. Selecting the “Delete” option will delete the “O” item. Selecting the “Clear All” will remove all the items in the “Mapping Sequence” list.

If you want to add “S” before “H” in the above “Mapping Sequence” list, click the “H” item in the list first, then press “S” in the “virtual keyboard” picture. If you want to append the codes at the end of the list, please make sure to select an empty mapping position in the list.

Caution:

1. Please pay special attention when using the Shift, Alt, and Ctrl keys as they have two states: down and up. For example, if you press the left Shift key once in the “virtual keyboard” area, you will only get a down code which will keep the key in a down state. If you were to keep this programming and press that key in an application, it would behave as if the left Shift key was down continuously. Again please pay special attention to the function of these keys and their respective up/down codes to get the functions you desire.
2. For PS2 interface, if <Pause> code is assigned, no other codes can be appended. On the other hand, if other code is assigned, the <Pause> code cannot be appended.
3. For USB interface, the following codes cannot be assigned with other codes: <Wake>, <Sleep>, <Power>, <Vol Up>, <Vol Down>, <Media Select>, <Mail>, <Calculator>, <My Computer>, <WWW Search>. On the other hand, if other code is assigned, the above codes cannot be appended.

Depending on the version of the software, you can change the virtual keyboard layout by selecting the country you like as shown below.




ii. ASCII Code

Using the ASCII method, you can assign any printable ASCII Codes, i.e. A-Z, a-z, 0-9, +, -, *, /, and punctuation symbols. Up to 255 ASCII codes can be assigned. Five special symbols can also be assigned by using the following representations:

Symbol	Representation
Enter Character	\n or \N
Esc Character	\e or \E
Tab Character	\t or \T
\ Character	\\
Delay 0.5 second	\d or \D
ASCII Code	\xHH where HH must be a two-digit hexadecimal integer

For example, if you program a key with “Hello\nWorld”, as shown in the following diagram,




After programming this button, if you type this button in Notepad, it will display,
Hello
World

Note:

1. Caps Lock will not modify the output of keys using this method. The key codes will always be output in the same way they are programmed in.
2. The output of the character string follows the Country Code setting in the Keyboard Setting dialogue (Refer to Section 3). For example, if you enter “How are you?” from the keyboard connected to your PC with a German OS, but you choose USA for the Country Code in the Keyboard Setting dialogue, the output will become “How are zou?”.

iii. Customize Code (For PS/2 keyboard only)

This method allows a user to directly assign PS/2 Set 2 Scan Codes for the key.



The codes entered in the “Make Code” field will be sent if the key is pressed down while the codes entered in the “Break Code” field will be sent when the key is pressed up. For example, the codes in the above diagram are the Scan Codes for left shift’s make code(12), h’s make code(33), h’s break code(f0 33), left shift’s break

code(f0 12), e's make code(24), e's break code(f0 24), l's make code(4b), l's break code(f0 4b), o's make code(44) and o's break code(f0 44).

Note:

1. Please enter the codes in hexadecimal format and use space to separate the codes.
2. Each code should have at most 2 characters (0-9, A-F or a-f).
3. Please do not use codes 00 or 02 as they are reserved by the program.


iv. Layer Index

Layers are useful in programming different codes to the same key. The output of the codes will be determined by the layer index which can be selected by another key programmed with the appropriate layer index code. There are at most 16 different programmable layers depending on the category of the keyboard. You can assign a layer index to any programmable key you like. Below is a screenshot of the Layer Index popup dialogue. After programming a layer index to a key, this key will be reserved on all layers.

Please DON'T program any other codes to those layer index keys again. The keylock




is recommended to assign the layer index.




Layer index keys can be regarded as performing a function much like the Shift key: when pressed and held down, it will output a different code than the base layer would normally send. For example if a key is programmed to output “hi” on layer 0 and “bye” on layer 1, it will output “hi” when pressed normally and “bye” when pressed while holding the key assigned to perform the “Layer 1 index” function (please see the following screenshots for further explanation).

①
Assign the
codes as "hi"




③
Assign the
codes as
"bye"



After programming this key map, if you press the X button in the keyboard, it will display “hi”. If you change the key lock to the position OP (or pressing the Y button without releasing), it will display “bye” if you press the X button.



To program key codes on alternate layers, please select each layer from the drop down menu located on the toolbar (shown in the below screenshot) and program key codes as explained in the previous sections. Please keep in mind that you must assign a corresponding layer index key to output layer-based codes. You may also assign layer indexes to the keylock if available (optional).



Another usage of the “Layer Index” is to lock the keyboard.

Here is one example showing how to achieve this.

1. Assign the layer index at position “L” for “Layer 0”. Kindly remind that DON'T assign any codes on keys under Layer 0.
2. Program key codes on alternate layers. Please select “Layer 1” from the drop down menu located on the toolbar and program key codes as explained in the previous sections.
3. Assign the “Layer 1” index at position “O”.
4. After programming, no key codes will be sent if you press any keys when the key lock is at the position LOCK. If you change the key lock to the position OP and press a programmed key, its key codes will be sent.




Note:


For some keyboards, the “LOCK” position is already implemented with the lock feature. That means, you need not program the above suggested steps, but still can lock the keyboard, the MSR and the external PS/2 keyboard (if any) when the keylock is at the LOCK position.

v. OPOS/JavaPOS Code (Optional)

Any keys and keylock positions can be assigned as an OPOS/JavaPOS key code. The assigned keys and keylock positions can be detected by any application using OPOS/JavaPOS driver.



Our OPOS driver is designed to support up to 180 OPOS Keys and 6 OPOS Keylock Positions.




Note:

1. For the details using our OPOS/JavaPOS, please read the readme files for the corresponding driver.

vi. Monitor Menu (Only for the keyboard with a 5.6” monitor display)

Any keys can be assigned to control the monitor. The available options are as shown below.



1. Menu Button – Display a menu in the monitor
2. Up Button – Move the cursor up in the menu

3. Down Button – Move the cursor down in the menu.
4. Left Button – Move the cursor to the left in the menu.
5. Right Button – Move the cursor to the right in the menu.
6. Power – To turn on/off the monitor.

Note:

The programmable keys assigned as these codes are effective only when the keyboard connected to the PC which is powered on.

3. Keyboard Setting

(This setting will not be provided if a RS232 magnetic card reader is selected in the Keyboard Category dialogue. If a PS2 or USB magnetic card reader is selected, only “Country Code” setting is meaningful.)

On the menu bar, click ‘Keyboard’ and then ‘Keyboard Setting’, the following dialogue window will appear,



Note:

The button “MSR Track 1 Mapping” is invisible for all PS2 and RS232 devices.


To make the keyboard beep upon pressing a key, please check the ‘Beep Enable’ box. You may then select if you would like all keys to beep or only programmed keys to beep when pressed down.

If you would like the key codes to be output repeatedly when pressing the button continuously, click ‘Repeat Enable’ option. If this is not selected the code associated with each key will only be output once even while holding down a key. [Caution: If you choose ‘Repeat Enable’ option and you assign non layer index for certain key lock

position, for example, assigning “Hello” for key lock L. When the key is switched on L position, “Hello” will be generated repeatedly. If you choose ‘Beep Enable’ at the same time, you will hear a continuous beep sound. Therefore, it is recommended the key lock be assigned a layer index.]

Depending on what type of keyboard chosen, you can assign a country code in the keyboard setting. This country code will affect what the MSR card reader (if available) and the keys programmed by the ASCII code method.

For a USB device with MSR function, you can change the default mapping for MSR Track 1 Data by pressing the button “MSR Track 1 Mapping”.



MSR Track 1 Mapping

Please enter one character for each mapping.

Space	(0	8	@	H	P	X
!)	1	9	A	I	Q	Y
"	*	2	:	B	J	R	Z
#	+	3	;	C	K	S	[
\$,	4	<	D	L	T	\
%	-	5	=	E	M	U]
&	.	6	>	F	N	V	^
'	/	7	?	G	O	W	_

Note:
The Country Code you set must be compatible with your OS language.


OK Cancel


Note:

To display the mapping correctly on your PC, you should choose the Country Code in the Keyboard Setting dialogue window compatible with your OS language.

After editing the settings, you may press ‘Update’ button to send them directly to the keyboard and then the dialogue window will be automatically closed or you may press ‘OK’ button to save the settings in the program memory (settings will not be transferred to the keyboard until you click the ‘Update Whole Keyboard’ button – see section 11 for more information).

4. Magstripe Card Reader Setting (Optional)

On the menu bar, click 'Keyboard' and then 'Magstripe Card Reader Setting', or on the toolbar, click  icon. The following dialogue window will appear,



The dialog box is titled "Magstripe Card Reader Setting". It features a central graphic of a magstripe card with three horizontal tracks. To the left of the card, under the heading "Start Sentinel", are three input fields for "Track 1", "Track 2", and "Track 3", each preceded by a checked checkbox. Track 1 contains a percent sign (%), while Tracks 2 and 3 contain semicolons (;). To the right of the card, under the heading "End Sentinel", are three input fields, each containing a question mark (?). Below the card is a "Reading Sequence" dropdown menu set to "1-2-3". On the left side, there is a checked checkbox for "Enable Beep". Below this is a section titled "Options <Some devices may not be supported>" containing six checkboxes: "Support IBM card", "Support OPOS", "Reverse reading", "Output data for any valid track", "Output credit card A/C No.", and "Enable LRC". A checkbox for "Shown in digital format" is located below the "Enable LRC" option. On the right side, there are three sections: "Header:" with "ASCII" and "Code" radio buttons (both unselected), "Separator:" with "ASCII" and "Code" radio buttons (both unselected), and "Suffix:" with "ASCII" and "Code" radio buttons (the "Code" button is selected). At the bottom right are "Update" and "OK" buttons.

The header, separator, and suffix can be programmed by clicking the ASCII or Code radio buttons. This will bring up a window for input similar to programming normal keys on the keyboard. For details, please refer to the sections "i. Key Code" and "ii. ASCII Code" under "2. Edit Key Map" section.

Options

The following settings are not supported by all devices. Please contact us for more information if you find that your device does not support these settings.

1. *Detect IBM card*

Some IBM cards have special formats. If you want to read the card correctly, you may try to select this option.

2. *Support OPOS*

It can be used in any system installed with OPOS/JavaPOS driver for MSR. Once it is checked, all MSR settings, except "Detect IBM card" will be disabled.

3. *Reverse reading*

The track data will be read from right to left, instead of from left to right. It is suitable for some languages, e.g. Hebrew.

4. *Output data for any valid track*

If there is an invalid track in the card, it still can display the remaining valid tracks.

5. *Output credit card A/C No.*

It can display the credit card A/C No. only for track 2.

6. *Enable LRC*

It can display the LRC after then end sentinel for each track.

7. *Shown in digital format*

If it is checked, the LRC will be displayed in the 2-byte digital format. If it is unchecked, the LRC will be displayed in the character format. For example, if the LRC in Track 1 is 0x31, it will display “31” when it is checked and it will display “Q” when it is unchecked.


Note:


1. The code length for Header, Separator, and Suffix are limited to 16 only.
2. For all RS232 devices, you can only enter 1 character for each sentinel. If you enter more than 1 character, the software will discard all characters.
3. For some PS/2 and USB devices, you can enter not more than 16 characters for each sentinel. You can use \n to represent the new line character in each sentinel.
4. For a RS232 device, they can only be programmed by using ASCII method.

According to the settings in the above dialogue window, after you slide a magstripe card along the reader, it will output the following information in order, Header codes, Track 1 Start Sentinel, Track 1 Data, Track 1 End Sentinel, Separator codes, Track 2 Start Sentinel, Track 2 Data, Track 2 End Sentinel, Separator codes, Track 3 Start Sentinel, Track 3 Data, Track 3 End Sentinel, Suffix codes.

After editing the settings, you may press ‘Update’ button to send them directly to the keyboard and then the dialogue window will be automatically closed or you may press ‘OK’ button to save the settings in the program memory (settings will not be transferred to the keyboard until you click the ‘Update Whole Keyboard’ button – see section 11 for more information).

5. Bar Code Reader Setting (Optional)


On the menu bar, click ‘Keyboard’ and then ‘Bar Code Reader Setting’, or on the toolbar, click  icon. The following dialogue window will appear,



The header and suffix can be programmed by clicking the ASCII or Code radio buttons. This will bring up a window for input similar to programming normal keys on the keyboard. For details, please refer to the sections "i. Key Code" and "ii. ASCII Code" under "2. Edit Key Map" section.

After editing the settings, you may press 'Update' button to send them directly to the keyboard and then the dialogue window will be automatically closed or you may press 'OK' button to save the settings in the program memory (settings will not be transferred to the keyboard until you click the 'Update Whole Keyboard' button – see section 11 for more information).

6. MICR Setting (Optional)

On the menu bar, click 'Keyboard' and then 'MICR Setting', or on the toolbar, click  icon. The following dialogue window will appear,

The image shows a 'MICR Setting' dialog box. At the top, there's a preview of the output format: '004567' followed by a series of vertical bars, then '123456789', another series of vertical bars, '123456780', another series of vertical bars, '000000234', another series of vertical bars, and finally 'ETX'. Below this, the 'Output Format' is set to 'STX', 'Auxiliary', 'Transit', 'On-US', 'Amount', and 'ETX'. The 'Enabled' checkboxes for 'Auxiliary', 'Transit', 'On-US', and 'Amount' are all checked. The 'Output Sequence' is set to '1st: Auxiliary', '2nd: Transit', '3rd: On-US', and '4th: Amount'. On the left, under 'Options', there are checkboxes for 'Enable MICR' (checked), 'Enable CMC-7' (unchecked), 'Enable Beep' (checked), 'Discard data after space at On-US field' (unchecked), and 'Send data if error' (checked). Below these are radio buttons for 'Always return check to entry' (selected), 'Never return check to entry', 'Return check to entry if good read only', and 'Return check to entry if bad read only'. There are also checkboxes for 'Hold at entry' and 'Hold at exit'. In the center, there are three mapping sections: 'E13B Mapping' with four items (each with 'ASCII' and 'Code' radio buttons), 'CMC-7 Mapping' with five items (each with 'ASCII' and 'Code' radio buttons), and 'Control Character Mapping' with eight items (each with 'ASCII' and 'Code' radio buttons). At the bottom right, there are 'Update' and 'OK' buttons.

The items in E13B Mapping, CMC-7 Mapping and Control Character Mapping can be programmed by clicking the ASCII or Code radio buttons. This will bring up a window for input similar to programming normal keys on the keyboard. For details, please refer to the sections "i. Key Code" and "ii. ASCII Code" under "2. Edit Key Map" section.


The Control Character Mapping, Output Sequence and Enabled options are effective only when a check of E13B type is read.


According to the settings in the above dialogue window, after you slide a check of E13B along the reader, it will output the following information in order,

STX, Header of Field 1 (1st Sequence: Auxiliary), Field 1 data, Suffix of Field 1, Header of Field 2 (2nd Sequence: Transit), Field 2 data, Suffix of Field 2, Header of Field 3 (3rd Sequence: On-US), Field 3 data, Suffix of Field 3, Header of Field 4 (4th Sequence: Amount), Field 4 data, Suffix of Field 4, ETX

After editing the settings, you may press 'Update' button to send them directly to the keyboard and then the dialogue window will be automatically closed or you may press 'OK' button to save the settings in the program memory (settings will not be transferred to the keyboard until you click the 'Update Whole Keyboard' button – see section 11 for more information).

7. iButton Setting (Optional)

On the menu bar, click 'Keyboard' and then 'iButton Setting', or on the toolbar, click  icon. The following dialogue window will appear,



The Leading, Header, Suffix and Ending can be programmed by clicking the ASCII or Scan Code radio buttons. This will bring up a window for input similar to programming normal keys on the keyboard. For details, please refer to the sections "i. Key Code" and "ii. ASCII Code" under "2. Edit Key Map" section.

The default settings for these 4 keys are:

Symbol	Values
Header	<Empty>
Suffix	Enter (Scan Code)
Leading	~~~~~ (ASCII)
Ending	~~~~~ (ASCII)

If you put the iButton on top of the sensor, it will output the following information in order, the values of Leading Symbol, the values of Header Symbol, Data stored on the iButton and the values of Suffix Symbol.

If you move out the iButton, it will output the values of Ending Symbol.

After editing the settings, you may press 'Update' button to send them directly to the keyboard and then the dialogue window will be automatically closed or you may press 'OK' button to save the settings in the program memory (settings will not be transferred to the keyboard until you click the 'Update Whole Keyboard' button – see section 11 for more information).

8. Firmware Update (Except for the USB device)

On the menu bar, click 'Keyboard' and then 'Update Firmware', or on the toolbar, click



icon. Navigate to the firmware file and click “OK”. This will begin the firmware update.

During updating, please do not press any keys on the keyboard or click the mouse or touch the touch panel for better performance.

9. Diagnostic

i. Enter Test Mode

Pressing a key will show that key’s position. (For testing the keyboard only.) If your keyboard has key lock feature and the repeat feature is turned on, the keyboard will continuously send the key lock position. To stop this, you can press any other key.

ii. Exit Test Mode

Pressing a key will show the code programmed to that key.

iii. Load Factory Setting

Reload the default factory setting to the device. This function can be used when the QUERTY section of the keymap is lost. For the USB keyboard, please re-plug the keyboard and close the software after executing this function successfully.

iv. Reset

Reset the keyboard only. (For testing the keyboard only.)

v. Ignore the middle device (For PS/2 device)

In case two of our PS/2 devices are connected by loop-through, you can directly program the device which is connected to the PS/2 port of your PC. But if you want to program the 2nd device, you need to ignore the middle device (i.e. the one which is connected to the PS/2 port of your PC) first.

Note: Once the middle device is ignored, it will be disabled.

vi. Restore the middle device (For PS/2 device)

To enable the middle device, you need to restore it first.

vii. Firmware Version


Get the current version of the firmware.

viii. MCU Type (Disabled)

Get the type of the MCU being used by the device.

10. Update Key Mappings

To send only the key mapping data to the keyboard device, click Keyboard > Update Key

Mappings on the menu bar or on the toolbar, click  icon.


During updating, please do not press any keys on the keyboard or click the mouse or touch the touch panel for better performance.

11. Update Whole Keyboard

To send the settings for the entire keyboard device (including MSR settings, Keyboard Settings, key mapping data, Barcode Settings, MICR Settings and iButton Settings), click Keyboard > Update Whole Keyboard on the menu bar.


During updating, please do not press any keys on the keyboard or click the mouse or touch the touch panel for better performance.

12. Retrieve Keyboard


To retrieve the data currently programmed to a keyboard device (including MSR settings, Keyboard Settings, key mapping data, Barcode Settings, MICR Settings and iButton Settings), click Keyboard > Retrieve Keyboard on the menu bar or click  icon on the toolbar.

During retrieving, please do not press any keys on the keyboard or click the mouse or touch the touch panel for better performance.


13. Clear All

To clear the data in the Matrix Maker program memory (including MSR settings, Keyboard Settings, and key mapping data), click Keyboard > Clear All on the menu bar or click  icon on the toolbar. This action only clears the Matrix Maker program memory - it does not clear the settings in the actual keyboard.

14. Save

To save all current settings in the Matrix Maker program memory to a file, click File > Save on the menu bar or click  icon on the toolbar.

15. Open

To open a saved Matrix Maker settings file, click File > Open on the menu or click  icon on the toolbar. An error may occur if you choose a setting file of a newer version on the Matrix Maker software with an older version.

16. Default Keymap

You can set the default key mappings for each model in the Matrix Maker by clicking File > Set Default on the menu bar. Once a key mapping is set as default, it will be automatically loaded the next time this model is selected.

IV. Batch Update

You can update the keymap or the firmware automatically by creating a batch file. After updating, the program will be closed automatically.

1. Keymap Update

The format of the batch file for updating keymap for a PS2 or USB device,

"Location_of_Executable_File"-1"Location_of_Keymap_File"-t"Category"

For example,

"C:\Program Files\Matrix Maker\Programmable Keyboard\MatrixMaker.exe"
-1"C:\temp\s78a.dat"-t"S78A"

The format of the batch file for updating keymap for a RS232 device,

"Location_of_Executable_File"-1"Location_of_Keymap_File"-t"Category"

-s"Port,Baud"

For example,

"C:\Program Files\Matrix Maker\Programmable Keyboard\MatrixMaker.exe"
-1"C:\temp\C202AC.dat"-t"C202AC" -s"1,57600"

2. Firmware Update (Except for the USB device)

The format of the batch file for updating firmware for a PS2 device,

"Location_of_Executable_File"-2"Location_of_Firmware_File"-t"Category"

For example,

"C:\Program Files\Matrix Maker\Programmable Keyboard\MatrixMaker.exe"

```
-2"C:\temp\poskb.bin"-t"S78A"
```

The format of the batch file for updating firmware for a RS232 device,

```
"Location_of_Executable_File"-2"Location_of_Firmware_File"-t"Category"  
-s"Port,Baud"
```

For example,

```
"C:\Program Files\Matrix Maker\Programmable Keyboard\MatrixMaker.exe"  
-2"C:\temp\poskb.bin"-t"C202AC" -s"1,57600"
```

Note:

- a.** There is a space before -1, -2, -t, and -s but no space after -1, -2, -t and -s.
- b.** The double quotation mark is required.